

SVENSKA

Baselementets talspolar är i sitt grundutförande seriekopplade till 4 Ohm.

Önskar du ansluta din nya **900PRO112** till ett monoblock som är 1 Ohm-stabilt behöver du:

1. Avlägsna gallret (det tvärgående gallret sitter intryckt i gummipluggar).
2. Avlägsna skruvarna (8 st).
3. Koppla ur basen från lådans terminal.
4. Parallellkoppla baselementets talspolar (se bild nedan).
5. Återansluta elementet till terminalen.
6. Skruva tillbaka skruvarna (använd originalskruvarna och de förborrade hålen) och sätta tillbaka gallret.

OBS. Detta bör endast utföras om ditt slutsteg är 1 Ohm-stabilt. OBS.

ENGLISH

The subwoofers voice coils are connected in series (4 Ohms).

If you wish to connect your new **900PRO112** to a mono amplifier that handles 1 Ohm you need to do the following:

1. Remove the speaker grilles (the protective grille bars are pressed in to rubber plugs).
2. Remove the screws (8 pcs).
3. Disconnect the subwoofer from the terminal.
4. Connect the voice coils in parallel (see image below).
5. Reconnect the subwoofer to the terminal.
6. Screw back the screws (use the original screws and holes) and reattach the protective grille bars.

Please note that this should only be carried out if your amplifier handles 1 Ohm.

